

Nauticam External Monitor Compatibility Table

	Housing		Camera HDMI Type	HDMI Output					SDI Output		
				17901 NA-DP4	17902 NA-NUJA-2	17903 NA-058	17904 NA-Shogun	17906 NA-502H	17903 NA-058	17905 NA-Shogun	17907 NA-502S
Cinema System	16101	NA-Red	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16102	NA-BMCC	x	*Atomos connector D2H/16211/16212/25060	*Atomos connector D2H/16211/16212/25060	*Atomos connector D2H/16211/16212/25060	*Atomos connector D2H/16211/16212/25060	*Atomos connector D2H/16211/16212/25060	✓	✓	✓
	16103	NA-BMPCC	D	25028/25032	25028/25032	25028/25032	✓	25028/25032	x	x	x
	16104	NA-Z100	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16105	120 7"LCD	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16106	120 5"LCD	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16107	120 5" LCD battery	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16108	120 502	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16131	200 5"LCD	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16132	200 7"LCD	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
	16133	Mini Housing	A	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable	* A-D HDMI cable/25033	* A-D HDMI cable	✓	✓	✓
Nikon System	17210	NA-D600	C	✓	✓	✓	x	✓	N/A		
	17213	NA-D800	C	✓	✓	✓	x	✓			
	17214	NA-D4S	C	✓	✓	✓	x	✓			
	17215	NA-	C	✓	✓	✓	x	x			
	17216	NA-D810	C	✓	✓	✓	x	✓			
	17217	NA-D750	C	✓	✓	✓	x	✓			
	17217	NA-D610	C	✓	✓	✓	x	✓			
	17218	NA-	C	✓	✓	✓	x	✓			
Canon System	17301	NA-7D	C	✓	✓	✓	x	✓	N/A		
	17306	NA-650D	C	✓	✓	✓	x	✓			
	17311	NA-6D	C	✓	✓	✓	x	✓			
	17312	NA-70D	C	✓	✓	✓	x	✓			
	17315	NA-5DMKIII	C	✓	✓	✓	x	✓			
	17316	NA-1DX	C	✓	✓	✓	x	✓			
	17319	NA-7DMKII	C	✓	✓	✓	x	✓			
	17320	NA-5DSR	C	✓	✓	✓	x	✓			
Micro 4/3 System	17708	NA-GX7	C	25028/25032	25028/25032	25028/25032	x	25028/25032	N/A		
	17709	NA-GH4	D	25028/25032	25028/25032	25028/25032	✓	25028/25032			
	17804	NA-EM5	D	x	x	x	x	x			
	17806	NA-EM1	D	x	x	x	x	x			
	17807	NA-EM10	D	x	x	x	x	x			
	17809	NA-EM5II	D	25028/25032	25028/25032	25028/25032	x	25028/25032			
Sony E-mount System	17403	NA-NEX7	C	25028/25032	25028/25032	25028/25032	✓	25028/25032	N/A		
	17407	NA-NEX6	C	25028/25032	25028/25032	25028/25032	✓	25028/25032			
	17410	NA-A7/A7s	D	✓	✓	✓	✓	✓			
	17411	NA-A5000	D	x	x	x	x	x			
	17412	NA-A6000	D	25028/25032	25028/25032	25028/25032	✓	25028/25032			
Fuji film	17313	NA-G16	D	x	x	x	x	x	N/A		
	17318	NA-G7X	D	x	x	x	x	x			
	17408	NA-RX100IIV	D	25028/25032	25028/25032	25028/25032	x	25028/25032			
	17413	NA-RX100III	D	25028/25032	25028/25032	25028/25032	✓	25028/25032			
	17415	NA-RX100IV	D	25028/25032	25028/25032	25028/25032	✓	25028/25032			
	17710	NA-LX100	D	25028/25032	25028/25032	25028/25032	✓	25028/25032			
	17808	NA-TG3	D	x	x	x	x	x			
Fuji film	17151	NA-XT1	C	25028/25032	25028/25032	25028/25032	x	25028/25032	N/A		
Canon EF-M System	17322	NA-EOS M3	C	25028/25032	25028/25032	25028/25032	x	25028/25032	N/A		

Remark:

- 1) '✓' means can be applied directly, no extra parts needed.
- 2) 'x' mean not compatible.
- 3) 's' means parts need out sourcing.
- 4) 'NA' means not available.
- 5) PN. filled in means the extra parts needed to be compatible.